ANDROID User Manual



Table of Contents

Table of Contents 1
1 Outlook Description 3
2 Power Button Usage 4
3 Touch-Screen Navigation 4
4 Transfer Box 4
5 Using microSD Card 5
6 Getting Started 5
- Charge the device 5
- Turn the device on 5
- Wi-Fi Network Setup 6

7 DESKTOP 6
8 Screen Lock 7
9 Pre-loaded Applications 7
10 Desktop Function Menu 9
11 Application Management 10
- Install Android Applications 10
- Download Android Applications direct from a Website 11
- Uninstalling Android Applications 11

12 WmtWeather 11
13 CLOCK 12
- Alarm 12

14 APP MARKET 13
- Download Applications 13
- App Market Function Menu 13

15 BROWSER 14
16 CALENDAR 14
- Add Event 14

17 CAMERA 14
- Take Pictures 15
- Take Videos 15

18 CALCULATOR 15
19 EMAIL 15
- Add Email accounts 15
- Email Inbox 16
- Edit Email Account 17
- Delete Email Accounts 17

20 FILE BROWSER 17
- Copy Media between Computer and Tablet 18

Delete files 18
21 MY MUSIC 19
Play Music 19
The Operation with Music and Playlist 19
22 MY VIDEO 20
Play Video 20
The Operation with Video and Playlist 20
23 MY PHOTO 20
Doodle 21
24 CONTACTS 21
Add New Contacts 21
Add Contact to Favorites 21
Edit Contacts 22
Delete Contacts 22
25 PICTURE CAPTURE 22
26 PK MANAGER 22
Stopping Applications 22
Uninstall Applications 23
27 YouTube 23
28 TUDOU 23
29 Wi-Fi Settings 23
30 3G Settings 24
31 ADSL Settings 25
32 Ethernet 25
33 SETTINGS 25
Frequently Asked Questions 27
Battery Management 28
Important Safety Precautions 28
Appendix: The Optional parts and models 29

1 Outlook Description

Front:



Right side:



Left side:

Top:

2 Power Button Usage

Turn On: Press the power button and hold for 2 seconds.
Turn Off: Press the power button and hold for 2 seconds, →tap **OK**.
Sleep Mode On/Off: Press & release the power button quickly to turn sleep mode on and off.
Force Off: If device does not respond, press and hold the power button for 5seconds.
Note: If it is necessary, we don't suggest use **Force Off**. You should follow the steps to perform the shutdown.
Reset Button: Press the reset button to reset the device. Reset will erase all data on the device, please caution this feature. (**Note:** Current the reset function can not be restart, so after reset you need to press the power button to re-boot.)

3 Touch-Screen Navigation

The touch-screen allows for quick, easy and convenient navigation for all applications.

☆ *The smaller the point that comes in contact with the screen, the more precise object selection can be. If you do not have long enough fingers nails to be used for precise tapping, we recommend using the stylus or non-sharp pointed instrument to increase the precision of navigation.*

Throughout the User Guide, you are instructed to use the following tap or touch navigation methods:

Tap: Quick tap & release on an item on the screen.
Finger slide: Touch & slide your finger across the screen and then release.
Touch & hold: Touch and hold in place approx 2 seconds, and then release to display an options window.

☆ *To avoid scratching or crushing, do not place objects on the touch screen surface.*

4 Transfer Box

You must use the transfer box if you want to use a USB storage device (U-disk) for accessing/storing your photos, music or video files.

Transfer Box

USB interface—connect the U disk

U-Disk

Insert your U-disk to the transfer box, → insert the transfer box into the Tablet. When ready for use, it's OK.

☆ *Don't insert and remove the U-disk repeatedly in a short time, as this may cause damage to the U-disk.*

The transfer box is also used for Ethernet network connections.

Ethernet interface

5 Using microSD Card

☆ *The device supports a maximum 32GB microSD card.*

Insert your card into the microSD slot until it clicks into place. it's OK

Remove microSD Card

Use one of the following methods for moving the microSD card.

Close all applications or documents which have been opened on the card. Tap → **Settings** → **SD card & device storage** → **Unmount SD card.** Press the card lightly; it is partially ejected allowing you to pull the card out.

☆ *Don't insert and remove the U-disk repeatedly in a short time, as this may cause damage to the card.*

☆ *We recommend using major brands of memory cards to avoid incompatibility.*

6 Getting Started

Charge the device

☆ *You cannot charge the battery using the USB cable.*

☆ *You can use the device while the battery is charging, although the charging time is longer when operating and charging at the same time.*

Plug the power adapter into an electrical wall outlet, and then connect to the device to fully charge the battery before use (approx. 4hour).

While charging, the battery indicator light is red. When fully charged, the battery indicator light is green.

Turn the device on

Press the power button and hold for 2 seconds.

Wi-Fi Network Setup

Since many features require a Wi-Fi connection, we recommend you set up your Wi-Fi network now.

1. Tap , → **Settings**, → **Wireless & network**.
2. Select **Wi-Fi** to turn on.

The device automatically scans and lists all local Wi-Fi Network found. A indicates secure networks that require login name/password to connect.

3. Tap the desired network to which you want to connect, → enter the **Network Password** if applicable, → tap **Connect**.
4. Tap to return to the Desktop screen.

☆ *If your Wi-Fi network is set as hidden, it won't be found by the auto scan. Tap* ***Add Wi-Fi network*** *and follow the prompts to add your network.*

7 DESKTOP

① Return to Desktop from other apps
② Battery charge status
③ Current Time
④ Picture capture icon
⑤ Volume reduction icon
⑥ Volume increase icon
⑦ Function Menu icon
⑧ Back icon
⑨ Tap to view the applications screen

☆ *Tap on any application icon to launch it.*

☆ *Touch, hold and then slide icons to reposition then on the screen.*

☆ *Touch, hold and slide icons onto to remove them from the* ***Desktop*** *screen.*

8 Screen Lock

Can be set to automatically lock screen or quickly press the power button to manually lock screen. Lock screen displays the following:

Tap the icon to enter My Photo to do slide show. And slide the track like the picture to unlock.

9 Pre-loaded Applications

	Wmtweather	Display the weather.
	Clock	Use as alarm clock with scheduled alarms.
	App Market	Downloaded applications quickly & easily.
	Browser	Access the Internet and "surf the web" whenever desired.

	Calendar	Calendar with ability to set events.
	Camera	Take photos and save to internal memory or your memory device.
	Calculator	Do calculation.
	Email	Send/Receive email using your existing email addresses.
	File Browser	File manager application for viewing and managing files and apps. Use to install Android apps, and to backup files to your SD card.
	My Music	Play and manage audio files.
	My Video	Play and manage video files.
	My Photo	View and manage photo files.
	Contacts	Create a list of personal contacts, which can also be linked with your email.
	Picture Capture	Capture image of the screen.
	PK Manager	Application manager for managing processes.
	YouTube	Quick launch to YouTube.com videos.
	Tudou	Quick launch to Tudou.com videos.
	Settings	Multiple settings for personalizing and enhancing your Device.

	Wi-Fi Settings	Set Wi-Fi network.
	3G Settings	Set 3G network.
	ADSL Settings	Set ADSL network.
	Ethernet	Configure Ethernet.

☆ *To move an icon to the* ***Desktop*** *screen, touch & hold on the icon, and then release it when it appears on the* ***Desktop*** *screen.*

☆ *Touch, hold and then slide icons to reposition then on the screen.*

☆ *Touch, hold and slide icons onto* *to remove them from the* ***Desktop*** *screen.*

10 Desktop Function Menu

On the **Desktop** screen, you can tap to display the **Function Menu**.

Add		The viewable portion of the **Desktop** screen allows only 16 icons. In order to add more items, finger slide the screen horizontally to expose available space, and then tap the **Add** icon again. If the screen is full, the **Add** icon won't response.
	Shortcuts	Add quick launch shortcuts on the **Desktop** to applications, bookmarks or settings. ☆ *If you select items that are*

		shortcuts already on the Desktop screen, they will be duplicated, resulting in multiple icons for the same item.
	Widgets	**Analog clock:** Add a round analog clock. **Calendar:** Add a calendar widget to display current date & events. **Music Player:** Add a music widget to quickly begin playing music without launching the music application.
	Folders	**New Folder:** Add a folder into which you can add applications as desired. To move applications on the Desktop screen into the folder, touch, hold & drag the icons directly on top of the folder icon. To add applications from the **All Application** screen, first tap on the folder to open it, open the **All Application** screen, and then touch & hold on an application icon. It is copied into the folder.
Wallpaper		Select wallpaper from **Picture** and **Wallpapers**.
Search		Perform a quick Google search. Tap in the entry field, → enter the desired search text, → tap .
Notifications		List any pending notifications (i.e., new email, calendar events, etc).
Settings		See "Settings" on page 25.

11 Application Management

Install Android Applications

☆ *There are many interesting and free Android applications that can be found on the web. Just launch your web browser and do a search for "Android applications".*

Purchased or free Android applications that you have downloaded to your computer can be installed quickly & easily on your Tablet using the **File Browser** application.

1. Copy the **.apk** files that you want to install onto a SD card or USB device, → insert or connect to your Device.
2. Tap the **File Browser** application icon.
3. Tap or and locate the folder in which the .apk application files were saved.
4. Tap on a **.apk** file → **Install**.
   The application is installed and the application icon is added to the **Applications** screen.
5. Tap **Open** to launch the application now, or tap **Done** to return to the **File Browser** screen.

Download Android Applications direct from a Website

You can download Android applications directly from websites, and then quickly and easily install them on your device.

1. Tap the **Web** application icon to launch the internet browser.
2. Enter the desired website URL, and tap the **download** link for the application you want to install on your device.
3. After the download is complete, touch & hold on the download file (in the **Download history** screen), → tap **Open** → **Install**.

Uninstalling Android Applications

You can also quickly and easily uninstall the Android applications that you have installed.

1. Tap → **Settings** → **Applications** → **Manage applications**.
2. Tap the application you want to uninstall, → **Uninstall**.
3. Tap **OK** to confirm the Uninstall.

12 WmtWeather

Tap the **WmtWeather** application icon.

General setting

You can set Temperature Unit(℃), Update frequency and Auto Wallpaper.

My cities

You can add city and set it to be my city.

You can make the weather displayed on the **Desktop** through adding widget. The way is: tap

→ Add → Widgets → WmtWeather.

13 CLOCK

Tap the **Clock** application icon. You can see the time and date.

Alarm

You can use your device as an alarm clock by setting multiple alarms.

☆ *This clock icon displayed at the top of screens indicates that one or more alarms have been set and are active.*

Add Alarm

1. Tap the **Clock** application icon.
2. Tap → **Add alarm**.
3. Set up your alarm as desired.

☆ *If you don't select a repeat, the alarm is automatically deleted after it is activated.*

4. Tap **Turn alarm on.**
5. Tap **Done.**

Shut Off Alarm Alert

When a scheduled alarm is activated, a pop-up window with the alarm title appears. Tap Snooze if you want to be reminded again in 10 minutes.

Tap Dismiss to cancel the alert.

Turn Alarm on

On alarms that you have set to repeat, you may want to temporarily turn on alarms rather than delete them.

1. In the Alarm screen, tap on the alarm(s) you want to turn on.
2. Tap to turn on again.

Edit Alarm

1. Tap the **Clock** application icon.
2. Tap on the alarm you want to edit, → make desired edits.

Delete Alarm

1. Tap the **Clock** application icon.
2. Tap on the alarm you want to delete.

3. Tap → **Delete alarm**.

Tap to return to the **Desktop** screen.

14 APP MARKET

The App Market has many applications that you can quickly and easily download to your Tablet.

Download Applications

1. Tap the **App Market** application icon.
2. You can select applications from the default **Featured** group, by **Categories**, **Top** (latest, hottest, random), or search by name.
3. Tap on an application, → **Download**.

☆ *The first time, you are prompted for your App Market login information. If you have not yet registered an account, tap **Register an Account**.*
*Otherwise, enter your login information and tap **Yes**.*

4. After the app is downloaded, tap **Install**.
5. Tap **Open** to launch now, or **Done** to return to the **App Market** screen.

History

After downloading apps, tap on **History** to manage the installed applications. You can add and/or view comments from other users, launch apps, and uninstall them.

App Market Function Menu

Tap to display the App Market **Function Menu**.

Profile

Tap to access your profile information. You can change your Password or Email address.

Login/Logout

Tap **Login** to quickly launch the login dialog box to login to your account. While logged in, tap **Logout** to exit your account.

Settings

By default, applications that you download are saved in the internal memory. You can set the applications to save to your SD card if desired.

About

Displays App store version and support information.

15 BROWSER

Users can connect to the Internet through a browser.

Click the browser icon on the Desktop and then you can open the Web browser.



16 CALENDAR

Tap the **Calendar** application icon.

For the first time using the **Calendar**, you need to add an Exchange account. Enter account email address and password. Click **Next** and follow the prompts to complete the account configuration. Then you can use the **Calendar**.

Add Event

1. On the **Calendar** screen, tap on the date to which you want to add an event.
2. Tap on the event time, → tap in each entry field to enter the desired event information.
3. Tap **Done**.
4. Tap to select desired **Calendar** screen.

☆ *Dates with green bars indicate scheduled events.*

17 CAMERA

Tap the Camera application icon.

Take Pictures

1. In **Camera** → tap to take the picture.
2. The picture will be saved.
3. Tap the picture thumbnail to enter **My Photo** to scan the picture.
4. Press **Back** to the **Camera**.
5. Tap to exit the **Camera** and back to the **Desktop**.

Take Videos

1. Tap switch to video, and you can take videos.
2. Tap to begin and tap to stop.
3. The video will be saved.
4. Tap the video thumbnail to play the video.
5. Press **Back** to the **Camera**.
6. Tap switch back to camera.
7. Tap to exit the **Camera** and back to the **Desktop**.

Note: You can tap to choose to save the files in the Localdisk or the SD card.

18 CALCULATOR

1. Tap the Calculator application icon.
2. Tap the numbers and sign of operation to do the calculation.
3. Tap **CLEAR** to clear the result one by one, tap and hold **CLEAR** to clear all.

19 EMAIL

☆ *POP3 and SMTP accounts are supported.*

Add Email accounts

You can enter one or more personal email addresses that you would like to access

through your Tablet.

1. Tap the **Email** application icon.
2. On the **Your Accounts** screen, tap **Next**.
3. Tap in the **Email** address entry field, → enter your email address.
4. Tap in the **Password** entry field, → enter your email password.
5. Tap **Done**.
6. **Manual Setup** *(optional)*: The server settings are automatically populated based on your email account provider *(i.e., gmail.com, etc)*. However, if you need to change the server settings tap **Manual Setup** and make necessary changes.
7. Tap **Next**.
8. Optional: Enter a name for the account.
9. Enter name for outgoing message, → tap **Done**.

☆ *After setup, if you are unable to connect to a free email account, check with your email provider to make sure their servers support free accounts on Post Office Protocol (POP) or Simple Mail Transfer Protocol (SMTP).*

Email Inbox

1. Tap the **Email** application icon.
2. If you set up only one email account, it opens immediately. If you set up multiple accounts, they are listed in the **Accounts** screen.
3. Tap on the desired email account, → tap **Inbox**.

Open Email Message

1. On the **Inbox** screen, tap on an email to open it.
2. For attachments, tap **Open** to launch appropriate application, or tap **Save** to save attachment to a SD card.
3. To replay, tap **Reply** or **Reply all**.
   a. Tap in the Compose Mail entry field to enter your reply message.
   b. Tap Send to send immediately, Save as draft to save without send or Discard to discard without saving or sending.
4. To delete the email immediately, tap **Delete**.

Compose New Email Message

1. On the Inbox screen, tap → **Compose**.
2. Tap in the **To** entry field and then enter the recipient's email address.
3. Optionally, if you want to add Cc or Bcc recipients, tap → Add Cc/Bcc, and then enter the recipient's email address.
4. Tap in the **Subject** entry field to enter your desired subject title.
5. Tap in the **Compose Mail** area to enter your personal message.
6. If desired, tap → **Add Attachment** to attach a file.
7. When ready to send the email, tap → **Send**.

Edit Email Account

1. Tap the Email application icon.
2. On the Inbox screen, tap → Account settings.
3. Set your desired preferences to customize your email account.
4. Tap to return to the Inbox screen.

Delete Email Accounts

☆ *If you have multiple accounts, and you delete the account designated as the default account, the next email listed is automatically set as the default.*

1. Tap the **Email** application icon.
2. On the **Inbox** screen, tap → **Accounts**.
3. Touch & hold on the account you want to delete.
4. In the pop-up **Account options** window, tap **Remove account**.
5. Tap **OK** to confirm the deletion.

Set Default Email Account

You must always have one account designated as the default account, so if you have multiple email accounts, you can select any one as the default.

1. Tap the **Email** application icon.
2. On the Inbox screen, tap → **Account Settings**.
3. Tap **Default Account** to select it.

If you delete the account that was designated as the default account, the next email listed is automatically designated as the default.

20 FILE BROWSER

Tap the **File Browser** application icon to view the files on all storage devices *(Internal memory, SD card, USB device)*, and to quickly & easily install Android application on your Tablet.

Use the icons across the top of the screen as follows:

Local disk (Internal memory)

Your SD card

U-disk/USB flash drive (using the included transfer box)

Transfer Box

USB interface—connect the U disk

Display precious folder

Create a new folder

Allows you to multi-select items

Copy Media between Computer and Tablet

You can use the File Browser to copy files between an external storage devices and your computer. You must first copy the desired files onto a SD card or USB device.

☆ *The internal device storage is titled "LocalDisk", a memory card "sdcard", and a USB storage device is titled "udisk".*

☆ *The instructions below are for copying from a SD card or USB storage device into the device. You can use the same method to copy from the device to a SD card or USB storage device, and then connect the storage device to your computer to transfer the files into the desired folder on your computer.*

1. Tap the or to display the contents of your storage device.
2. Tap and hold in the folder/file you want to copy, → tap **Copy**.
3. Tap on the Internal Memory, → tap on the folder into which you want to copy the file, → tap **Paste**.

Delete files

Tap and hold on the folder/file you want to delete, → tap **Delete** → **OK** to confirm the deletion.

21 MY MUSIC

☆ *Audio file formats supported: MP2, MP3, WAV, AAC, WMA.*

Play Music

1. Tap the **My Music** application icon.
2. Select an audio file from All/Albums/Artists/Directories/My Favourites/User Defined Playlists to play it.
3. To stop the music, tap the **Pause** icon.
4. To leave the music playing and return to previous screens, tap or tap to return to the **Desktop** screen.

Tap the photo on the left corner can enter the Music Player interface. It shows like:

At this interface, you can do: view the lyrics, play / pause, switch to the previous / next, added to favorites, loop and random operation etc.

The Operation with Music and Playlist

Add playlist

1. Tap on the left corner.
2. Input the playlist name.
3. Tap **Add**.

Rename or Delete playlist

Tap and hold in the playlist, → tap **Rename** or **Delete**.

Add music

1. Tap and hold in the music you want to add, → tap **Add**.
2. Click the following item to add music in it (if you don't want to add, tap Cancel).

Delete music

Tap and hold in the music you want to delete, → tap **Delete**.

22 MY VIDEO

☆ *Video file formats supported: MPEG1/2/4、MJPG、H263、H264. In addition to H264 which is supported by (720× 480) resolution, the other video formats are supported (1280×720) resolution.*

Play Video

1. Tap the **My Video** application icon.
2. Select a video file from All/ Directories/My Favourites/User Defined Playlists to play it.
3. Tap on the screen to display video controls (adjust volume, pause/play, previous/next, adjust brightness).
4. Tap **Back button** or to return to the **My Video** screen.

The Operation with Video and Playlist

Add playlist

1. Tap on the left corner.
2. Input the playlist name.
3. Tap Add.

Rename or Delete playlist

Tap and hold in the playlist, → tap **Rename** or **Delete**.

Add video

1. Tap and hold in the video you want to add, → tap **Add**.
2. Click the following item to add video in it (if you don't want to add, tap Cancel).

Delete video

Tap and hold in the video you want to delete, → tap **Delete**.

23 MY PHOTO

☆ *Photo file formats support: JPG, JPEG, BMP, and PNG.*

1. Tap the **My Photo** application icon, → tap on a group of photos.
2. To view individual photo, tap on the desired photo.
3. Tap Back button to return to the photo gallery screen.

4. Tap to make slideshow. There is Normal play, Reminiscently, Activity, Romantic, Tranquil and Fresh.
5. Tap to make the picture sort by color.
6. Tap to make the picture sort by time.
7. Tap to make the picture sort by name.

After entering a group of photos, tap and hold on a picture to enter multiple selections state. In the multiple selection state you can delete photos, and do dynamical switching wallpaper setting.

1. — Multiselect.
2. — Delete.
3. — Dynamical switching wallpaper setting.

Doodle

In **My Photo** you can do doodle.

Click the icon to enter doodle interface. You can select different doodle operations, including: word balloons, titles, stickers and brush.

24 CONTACTS

You can create an address book of your personal contacts, including personal notes as desired.

Add New Contacts

1. Tap the **Contacts** application icon.
2. Tap → **New Contact.**
3. Tap in the name fields to enter the contact's first & last name.
4. Tap at the right of options to reveal additional choices.
5. Tap on the option name to reveal choices.
6. Tap in the option entry fields to enter the contact's information.
7. Tap **Done**.

Add Contact to Favorites

1. In the **Contacts** screen, tap on the desired contact name.

2. Tap in the upper right corner.
3. Tap to return to the **Contacts** screen.
4. Tap **Favorites** to view list of favorite contacts.

Edit Contacts

1. In the **Contacts** screen, tap on the desired contact name you want to edit.
2. Tap → **Edit Contact.**
3. Make desired changes, → tap **Done**.

Delete Contacts

1. In the **Contacts** screen, touch & hold on the contact, → tap **Delete contact**.
   OR
   In the **Contacts** screen, tap on the contact you want to delete, tap → **Delete Contact.**
2. Tap **OK** to confirm the deletion.

25 PICTURE CAPTURE

You can capture a screen image by tapping at any time.

Tap the **Picture Capture** application icon to set options for a screen capture.

- Select a delay timer to automatically capture the screen in desired number of seconds.
- Select the default storage device for saving your images.

After the images are saved, they can be viewed though **My Photo** application.

26 PK MANAGER

Use PK Manager to manager applications and widgets.

Stopping Applications

Android does not automatically stop applications after they are loaded, so you can manually stop the applications as desired.

1. Tap the **PK Manager** application icon. The list of applications that are running is displayed.
2. Tap on an application you want to stop, → tap **Force stop**.

Uninstall Applications

1. Tap the **PK Manager** application icon. The list of applications that are running is displayed.
2. Tap , → tap **Third Party** or **All** to list more applications.
3. Tap on an application you want to uninstall, → tap **Uninstall**.
4. Tap **OK** to confirm uninstall.

27 YouTube

1. Tap the **YouTube** application icon to view *YuTube.com* videos.
2. Tap on a video to launch it.
3. Tap on the screen to display video controls (adjust volume, pause/play, previous/next, adjust brightness).
4. Tap **Back button** to return to the **YouTube** screen.

28 TUDOU

1. Tap the **Tudou** application icon to view *Tudou.com* videos.
2. Tap on a video to launch it.
3. Tap on the screen to display video controls (adjust volume, pause/play, previous/next, adjust brightness).
4. Tap **Back button** to return to the **Tudou** screen.

29 Wi-Fi Settings

Tap **Wi-Fi Settings** application icon.

1. Select the box behind to open Wi-Fi;
2. All the AP in the vicinity will be listed, click to select the name you want to connect to

AP;

3. If the AP is connected successful before, the AP information will be saved in the pop-up window, select "Connect" starts to connect, choose "forget" to remove AP information;
4. If the AP is not encrypted, in the pop-up window, select "Connect" Start Connection;
5. If the AP is encrypted, enter the password in the pop-up window, and click "Connect" Start Connection;
6. When internet connections are successful, the wireless connection icon in the status bar appears.

30 3G Settings

First of all you need to buy 3G wireless network card according to China Telecom, China Mobile or China Unicom. The currently supported on the 3G card type please refer to Appendix.

We strongly recommend on buy the 3G Network Cards, in order to ensure normal 3G Internet access. Please come to the prepaid card into the purchase of 3G Network Cards, and then insert the adapter cards 3G on the box. At this time it will be bright lights on the 3G network card, which indicated that it could begin to connect the 3G network.

Tap **3G Settings** application icon.

Tap "**Add 3G network**":

Name: In the popup dialog box, name field enter the name you want free you can.

Device: If you use this manual in the format described in China Unicom's 3G network cards and device column to the default settings, you do not need to select other items; When you use the manual as described in the 3G standard of China Telecom on the card, the device should be chosen CDMA2000(Bora9380/AWIT-U8); When you use the manual as described in the 3G standard of China Mobile on the card, the device should be chosen TD-CDMA(TD368) Modem.

Device number and APN: Please fill in the information provided by carriers. (As in China: If you use China Unicom and China Mobile's 3G network card, device number field need to fill in "*99#", APN need to fill in the "cmnet"; if China Telecom formats 3G on the card, phone number need to fill in the column "T#777", APN do not need to fill in the name of column.)

User and Password: If you use the standard of China Unicom and China Mobile's 3G network card, user and password fields are free to fill or not fill; if you use the standard of China Telecom's 3G network card, user and password fields, please request to China Telecom.

Fill then click the link, and you will see the screen above the status bar 3G symbol appears, indicating the completion of 3G is connected, and then you can get online.

31 ADSL Settings

Tap **ADSL Settings** application icon.

Input name and password then click connect to access the broadband network.

32 Ethernet

Make the transfer box connected to the USB switch interface of the device, and then plug the network cable into the Ethernet port of the transfer box, in the upper right corner of the screen appears "ETH".

Tap **Ethernet** application icon.

The device can automatically access network IP address connection. And you can choose manual setup IP address to get a connection.

33 SETTINGS

Wireless & networks	**Wi-Fi**	Turn on Wi-Fi.
	Wi-Fi Settings	Set up & manage wireless access points.
	Airplane mode	Disable all wireless connections.
	3G network settings	Set up 3G network.
Ethernet		Configure Ethernet.
Pppoe settings		Do ADSL settings. Input user name and password to connect.
USB	**Mass storage**	Configure USB to mass storage.
	ADB	Configure USB to ADB.
Sound	**Silent mode**	Silence all sounds except media & alarms.
	volume	To adjust the Media volume, Alarm volume and Notification volume. Tap & slide and then tap **OK**.
	Notification ringtone	Select desired ringtone sound.
	Audible selection	Select to enable a sound when making a screen selection.
	Screen lock sounds	Play sounds when locking and unlocking the screen.

Display	**Brightness**	Tap & slide to adjust the screen brightness as desired, and then tap **OK**.
	Auto-rotate screen	When selected, the orientation of the screen switches between Portrait and Landscape automatically when you rotate the device.
	Screen timeout	Adjust the delay before the screen automatically turns off.
	Suspend timeout	Adjust the delay before the device automatically suspend after the screen turn off.
Security	**Set up screen lock**	Lock screen with a pattern, PIN, or password.
	Visible passwords	Show password as you type.
	Select device administrators	Add or remove device administrators.
	Use secure credential	Allow applications to access secure certificates and other credentials.
	Install from SD card	Install encrypted certificates from SD card.
	Set password	Set or change the credential storage password.
	Clear storage	Clear credential storage of all contents and rest its password.
Applications	**Unknown sources**	Allow installation of non-Market applications.
	Manage applications	Manage and remove installed applications.
	Running services	View and control currently running services.
	Development	Set options for application development.
Privacy	**Factory data reset**	Tap to reset the device to its initial factory state, erasing all data and downloaded applications. Tap **Reset Device** to proceed with reset, or tap to cancel and return to previous screen. WARNING! The following will be erased during the factory reset: ~ Google account ~ System and application data and settings ~ Downloaded applications The factory reset will NOT erased: ~ Current system software and bundled applications ~ SD card files, such as music or photos
SD card & device storage	**Total space, Available space**	It values appears when a SD card is inserted in device.
	Unmount SD card	When the SD card is inserted, tap it to safety remove the SD card.
	Format SD card	N/A for this device.
Language & keyboard	**Select language**	Select the language and region according to your location.
	Android keyboard	Onscreen keyboard settings.

	User dictionary	You can add words to a personal dictionary, words that may not be included in the default dictionary.
Date & time	**Set date**	Set the date.
	Select time zone	Select the time zone.
	Set time	Set the time.
	Use 24-hour format	You can choose to use 24-hour format or 12-hour format.
	Select date format	You can select the date format.
About device		View Status (Battery, Wi-Fi, etc), Battery use, Legal information, Model number, Android version, Kernel version and Build number.
Touchpanel calibration		Calibrate the touch screen.

Frequently Asked Questions

Android

Q: What Android OS version is on my Device?

A: 2.2

Basic Device Functionary

Q: Do I have to charge the battery before use?

A: You should charge the battery for at least 4 hours, but you can use the device while it's charging. Use the include power adapter to charge; this device does not charge via the USB cable.

Email

Q: Can I use any of my personal email addresses to send/receive email?

A: The device supports POP3 and SMTP accounts. Some free email accounts are not supported on mobile devices. Check with your email provider to see if you account is supported.

Media Cards

Q: Which media cards are compatible with my Device?

A: micro SD cards.

Music

Q: What type of music files can I play on my device?

A: MP2, MP3, WAV, AAC, WMA

Q: How do I add music files to my device?

A: Copy the music files from your computer onto a SD card or USB storage device, and then use the File Browser application to copy the files into the device.

Photos

Q: What type of photo files can I view on my device?

A: JPG, JPEG, BMP and PNG.

Q: How do I add photo files to my device?

A: Copy the photo files from your computer onto a SD card or USB storage device, and then use the File Browser application to copy the files into the device.

Video

Q: What type of video files can I play on my device?

A: MPEG1/2/4、MJPG、H263、H264. In addition to H264 which is supported by (720 × 480) resolution, the other video formats are supported (1280 × 720) resolution.

Q: Can I play YouTube videos on my device?

A: Yes. You can tap the YouTube application icon to quick access videos.

Q: How do I add video files to my device?

A: Copy the video files from your computer onto a SD card or USB storage device, and then use the File Browser application to copy the files into the device.

Wi-Fi

Q: Do I need a Wi-Fi adapter to connect to the Internet?

A: No. The Wi-Fi adapter is built-in to the device.

Battery Management

The battery is not fully charged out of the box, so it is recommended that you charge the battery for at least 4 hours before you start to use the device.

The rechargeable battery is designed and manufactured to be used and recharged frequently. As with all batteries, the capacity of the battery reduces each time it is charged/depleted. However, you can still try to prolong the battery's lifetime by following the suggestions below:

- Use your Tablet at least once a week.
- Charge the battery regularly and fully.
- Never leave the battery fully discharged for a long period of time.
- Always keep the device and the battery away from heat.

Charge battery

Plug the power adapter into an electrical wall outlet, and then connect to the device to fully charge the battery before use (approx. 4hour).

☆ *You cannot charge the battery using the USB cable.*

When fully charged, the battery icon displays as: .

A fully discharged battery takes approximately 5 hours to fully charge, but you can use the device while plugged in when desired.

Important Safety Precautions

Always follow these basic safety precautions when using your Tablet. This reduces the risk of fire, electric shock, and injury.

- Do not expose this product to rain or moisture.
- Keep the device out of direct sunlight and heat sources.
- Protect the power cord. Route power cords so that they are not likely to be walked on or pinched by items placed on or against them. Pay particular attention to the point where the cord attaches to the device.
- Only use the AC adapter included with the device. Using any other power adapter voids your warranty.
- Do not remove the cover. There are no user-serviceable parts inside.

Clean your Device

Treat the screen gently. To clean fingerprints or dust from the screen, we recommend using a soft, non-abrasive cloth such as a camera lens cloth.

Appendix: The Optional parts and models

Parts name	Parts type	
3G Wireless Network Card	TD-CDMA	TD368
	WCDMA	HUAWEI E220
		HUAWEI E230
		HUAWEI E160X
		HUAWEI E169G
		HUAWEI E1750
		Alcatel X060S
		Alcatel X200
	CDMA2000	Bora 9380
		AWIT-U8